PART NO. **5685**

CHEVROLET CAMARO FRONT MUD GUARD INSTALLATION INSTRUCTIONS

Please read instructions thoroughly before installation.

Tools Required


- Socket Wrench / Torx TR 15 Bit
- Phillips Head Screw Driver
- Drill / 1/8 Drill Bit

Package Contents

- Driver & passenger side front mud guard
- Instruction sheet
- #10 SEM Screws (Qty 4)

NOTE: It may be necessary to remove the wheels depending on the tools being used for installation.

1. Clean and degrease the mud guard location area on the fender before installation.
2. Remove existing fastener from locations C and D.
3. Using the mudguard as a template mark and drill a 1/8” hole in locations A and B.
4. Attach mud guard at locations C and D to fender with existing fasteners. Check fit and level before tightening.
5. Install #10 SEM screws at locations A and B.



PAINTING INSTRUCTIONS

Note: If painting mud guards, perform a mud guard test fit to ensure correct fit and application prior to painting.

1. Clean mud guard with a soap and water solution to remove dirt and other contaminates.
2. Sand painting surface with 320 grit sand paper.
3. Apply a coating of flexible primer-adhesion promoter.
4. Apply a flexible paint as directed by the paint manufacturer.